



FACTOR

ELEKTRİKLİ BOYA/HARÇ KARIŞTIRICI
KULLANMA KILAVUZU

CM1600



Bu kullanım talimatlarında veya cihaz üzerinde aşağıdaki simgelere yer verilebilir.



UYARI – Yaralanma riskini en aza indirmek için kullanıcı, kullanım kılavuzunu okumalıdır.



Asbest içeren malzemelerle çalışmayın.



Toz maskesi kullanın.



Koruyucu gözlük takmadan çalışmayın.



Kulak koruyucu takın



Sınıf II cihaz



Ambalaj ve cihazı çevre dostu yöntemlerle imha edin.

GİRİŞ

Lütfen cihazı ilk kez kullanmadan önce çalışma prensibini tam olarak öğrenin ve elektrikli el aletlerini doğru şekilde nasıl kullanacağınızı anlayın. Bunu sağlamak için lütfen beraberinde verilen kullanım talimatlarını dikkatlice okuyunuz. Bu talimatları güvenli bir yerde muhafaza edin.


Cihazı başka birine devredecekseniz, lütfen tüm dokümantasyonun da teslim edildiğinden emin olunuz.

DOĞRU KULLANIM

Makine yalnızca beton, çimento veya boya karıştırmak için tasarlanmıştır. Yanlış kullanım cihaza zarar verebilir. Cihazın başka amaçlarla kullanılması veya üzerinde yapılacak herhangi bir değişiklik yanlış kullanım olarak kabul edilir ve ciddi kaza riski doğurabilir. Üretici, yanlış kullanımdan kaynaklanan kayıp veya zararlardan sorumluluk kabul etmez. Cihaz ticari kullanım amaçlı değildir.

ÖZELLİKLER

1. Açma / Kapama butonu
2. Buton kilidi
3. Hız ayar tekerleği
4. Hız seçici anahtar
5. Alet montaj noktası
6. Ek tutamak
7. Hava alma delikleri
8. Anahtar (çark anahtarı)
9. Karıştırıcı Uç (Çırpıcı)



DAHİL OLAN PARÇALAR

2 adet anahtar

1 adet kullanım kılavuzu

TEKNİK ÖZELLİKLER

Çalışma Voltajı	: 230V ~ 50 Hz
Motor Gücü	: 1600W
Boşta Devir Sayısı	: I: 240-500/dak, II: 380-850/dak.
Mil Çapı	: M14
Karıştırıcı Çapı	: ø140 mm
Ağırlık	: 5.0 kg
Koruma Sınıfı	: II / 

GÜRÜLTÜ VE TİTREŞİM VERİLERİ

Değerler EN 60745 standardına uygun olarak belirlenmiştir.
Cihazın ses basınç seviyesi (LpA) tipik olarak 88,3 dB (A)'dır. Belirsizlik K = 3 dB.
Cihazın ses gücü seviyesi (LwA) tipik olarak 99,3 dB (A)'dır. Belirsizlik K = 3 dB.

Kulak koruyucu kullanın! 

Ana Tutamak
Maksimum titreşim yayılım değeri: 1,812 m/s²; Belirsizlik K = 1,5 m/s²

Yardımcı Tutamak
Maksimum titreşim yayılım değeri: 2,439 m/s²; Belirsizlik K = 1,5 m/s²

Not :
Beyan edilen toplam titreşim değeri, standart bir test yöntemiyle ölçülmüştür ve bir aletin diğerleriyle karşılaştırılmasında kullanılabilir.
Beyan edilen toplam titreşim değeri ayrıca maruziyetin ön değerlendirmesinde de kullanılabilir.

Uyarı :
Elektrikli el aletinin gerçek kullanımı sırasında titreşim yayılımı, cihazın kullanım şekline bağlı olarak beyan edilen toplam değerden farklılık gösterebilir; titreşim riskinden kaçınmak için öneriler:
1) Çalışma sırasında eldiven kullanın
2) Çalışma süresini sınırlayın ve tetik süresini kısaltın

GENEL ELEKTRİKLİ EL ALETİ GÜVENLİK UYARILARI

UYARI : Tüm güvenlik uyarılarını ve talimatları okuyunuz. Uyarılara ve talimatlara uyulmaması elektrik çarpması, yangın ve/veya ciddi yaralanmalara yol açabilir.

Tüm uyarıları ve talimatları ileride başvurmak üzere saklayınız.

Uyarılardaki "elektrikli el aleti" terimi, şebeke elektriği ile çalışan (kablolu) veya batarya ile çalışan (kablolu) elektrikli el aletinizi ifade eder.

1. Çalışma Alanı Güvenliği

- a) Çalışma alanını temiz ve iyi aydınlatılmış tutun. Dağınık veya karanlık alanlar kazalara yol açabilir.
- b) Parlayıcı sıvılar, gazlar veya toz gibi patlayıcı ortamlarda elektrikli el aletlerini kullanmayın. Elektrikli el aletleri kıvılcım çıkarabilir ve bu toz veya gazların tutuşmasına neden olabilir.
- c) Elektrikli el aleti kullanırken çocukları ve çevredeki kişileri uzak tutun. Dikkat dağınıklığı kontrolünüzü kaybetmenize yol açabilir.

2. Elektrik Güvenliği

- a) Elektrikli el aleti fişleri, prizle uyumlu olmalıdır. Fişi hiçbir şekilde değiştirmeyin. Topraklı (topraklama yapılmış) elektrikli aletlerde adaptör fiş kullanmayın. Değiştirilmemiş fişler ve uyumlu prizler elektrik çarpması riskini azaltır.
- b) Vücudunuzun borular, radyatörler, ocaklar ve buzdolapları gibi topraklı yüzeylerle temasından kaçının. Vücudunuzun topraklanması elektrik çarpması riskini artırır.
- c) Elektrikli el aletlerini yağmur veya nemli ortamlara maruz bırakmayın. Su girişi elektrik çarpması riskini yükseltir.
- d) Kabloya zarar verici davranışlardan kaçının. Kabloyu taşımak, çekmek veya elektrikli aleti prizden çekmek için kullanmayın. Kabloyu ısı, yağ, keskin kenarlar veya hareketli parçalardan uzak tutun. Hasarlı veya dolanmış kablolar elektrik çarpması riskini artırır.
- e) Elektrikli el aletini dış mekanda kullanırken, dış mekan kullanımı için uygun bir uzatma kablosu kullanın. Dış mekan kullanımı için uygun kablo elektrik çarpması riskini azaltır.
- f) Nemli ortamlarda elektrikli el aletini kullanmak zorundaysanız, artık akım koruma cihazı (RCD) korumalı bir elektrik kaynağı kullanın. RCD kullanımı elektrik çarpması riskini azaltır.

3. Kişisel Güvenlik

- a) Dikkatinizi kaybetmeden, ne yaptığınıza dikkat ederek ve sağduyulu davranarak elektrikli el aletini kullanın. Yorgun, uyuşturucu, alkol veya ilaç etkisi altındayken elektrikli alet kullanmayın. Dikkatsizlik, ciddi kişisel yaralanmalara yol açabilir.
- b) Kişisel koruyucu donanım kullanın. Her zaman koruyucu gözlük takınız. Toz maskesi, kaymaz iş ayakkabısı, baret veya ısıtma koruyucu gibi uygun şartlarda kullanılan koruyucu ekipmanlar kişisel yaralanmaları azaltır.
- c) İstenmeyen çalıştırmayı önleyin. Elektrikli aleti güç kaynağına ve/veya batarya paketine bağlamadan, cihazı almadan veya taşımadan önce aç/kapa butonunun kapalı konumunda olduğundan emin olun. Aç/Kapa butonu açıkken parmağınızı butonun üzerinde tutarak cihazı taşımak veya buton açık konumda iken elektrikli cihazı enerjiye bağlamak kazalara davetiye çıkarır.
- d) Elektrikli cihazı çalıştırmadan önce ayar anahtarını veya penseyi çıkarın. Dönen parçalara takılı kalan anahtar veya pense kişisel yaralanmalara neden olabilir.
- e) Aşırı uzanmayın. Her zaman dengeli durun ve sağlam basın. Bu, beklenmedik durumlarda elektrikli aleti daha iyi kontrol etmenizi sağlar.
- f) Uygun kıyafet giyin. Bol giysi veya takı takmayın. Saçlarınızı, giysilerinizi ve eldivenlerinizi hareketli parçalardan uzak tutun. Bol giysi, takı veya uzun saç hareketli parçalara takılabilir.
- g) Toz emme ve toplama sistemlerinin bağlantısı için donanım sağlanmışsa, bunların bağlandığından ve doğru şekilde kullanıldığından emin olun. Toz toplama sistemlerinin kullanımı, tozla ilgili riskleri azaltır.

4. Elektrikli El Aletinin Kullanımı ve Bakımı

- a) Elektrikli el aletini zorlamayın. Uygulamanız için doğru elektrikli el aletini kullanın. Doğru alet, tasarlandığı hız ve kapasitede işi daha iyi ve güvenli yapar.
- b) Aç/Kapa butonu çalışmayan elektrikli el aletini kullanmayın. Aç/Kapa butonu kontrol edilemeyen aletler tehlikelidir ve mutlaka tamir edilmelidir.
- c) Herhangi bir ayar yapmadan, aksesuar değiştirmeden veya aleti depolamadan önce, fişi güç kaynağından ve/veya batarya paketini elektrikli aletten çıkarın. Bu önleyici güvenlik önlemleri, aletin yanlışlıkla çalışmasını engeller.
- d) Kullanılmayan elektrikli cihazları çocukların erişemeyeceği yerde saklayın. Elektrikli el aleti ve bu talimatlara aşina olmayan kişilerin cihazı kullanmasına izin vermeyin. Elektrikli el aletleri eğitimsiz kişilerin elinde tehlikelidir.
- e) Elektrikli aletlerin bakımını yapın. Hareketli parçaların hizalanmasını veya sürtünmesini, parçaların kırılmasını ve aletin çalışmasını etkileyebilecek diğer durumları kontrol edin. Hasarlıysa, kullanmadan önce tamir ettirin. Birçok kaza, kötü bakımlı aletlerden kaynaklanır.
- f) Kesici takımları keskin ve temiz tutun. Keskin kesici kenarlara sahip, iyi bakımlı takımlar sürtünmeyi azaltır ve kontrolü kolaylaştırır.
- g) Elektrikli el aletini, aksesuarlarını ve uçlarını bu talimatlara uygun olarak ve çalışma koşulları ile yapılacak işe göre kullanın. Elektrikli aleti amaç dışı kullanmak tehlikeli durumlara yol açabilir.

5. Servis

- a) Elektrikli el aletinizi, sadece orijinal yedek parçalar kullanarak yetkili bir servise tamir ettirin. Bu, elektrikli el aletinin güvenliğinin korunmasını sağlar.

Dikkat! Altyapı Tesisatları!

TEHLİKE! Elektrikli el aleti ile çalışırken elektrik kablolarına, gaz veya su borularına zarar vermediğinizden emin olun. Delik açmadan veya yarık kesmeden önce uygun bir dedektörle duvarı kontrol edin.

Orijinal Aksesuarlar / Aparatlar

Kullanım talimatlarında belirtilen aksesuarları ve aparatları kullanınız.

Kullanım talimatlarında önerilmeyen aletlerin veya aksesuarların kullanılması, yaralanma riskine yol açabilir.

İLK KULLANIMDAN ÖNCE

UYARI! YARALANMA TEHLİKESİ!

Cihaz üzerinde herhangi bir işlem yapmadan önce cihazı kapatın ve fişi prizden çekin.

Karıştırıcı Uç Takılması

NOT: Sadece belirtilen çapta karıştırıcı uç (çirpıcı) kullanınız.

Karıştırıcı Ucunu (Çirpıcıyı) (M14 dişli) mümkün olduğunca cihaza vidalayın. Açık ağızlı anahtar ile Karıştırıcı ucu (çirpıcıyı) sağlam bir şekilde sıkın.

İlk Kullanım

Prizdeki şebeke voltajı, cihaz üzerindeki etiketle belirtilen voltaj ile uyumlu olmalıdır.

Kullanım

Yanlış kullanım cihaza zarar verebilir. Bu nedenle aşağıdaki talimatlara uyunuz: Belirtilen çap sınırına uygun bir aparat kullanın.

Aleti, hızın önemli ölçüde düşmeyeceği veya durmayacağı şekilde yükleyin.

Etiket üzerindeki verilerin mevcut şebeke voltajı ile uyumlu olup olmadığını kontrol edin.

Açma ve Kapatma

Cihazı açmak için Aç/Kapa butonuna (1) basılı tutun.

Aç/Kapa butonunu bıraktığınızda alet kapanacaktır.

Düğme Kilitleme Mekanizması

Aç/Kapa butonuna (1) bastıktan sonra düğme (2) ile kilitleyebilirsiniz. Kilit, Aç/Kapa butonuna kısa bir süre basılarak açılabilir.

Sürekli Ayarlanabilir Hız Ayarı

Hız seçici anahtarı (4) ile iki devir aralığı önceden seçilebilir:

Vites 1 220-500 /dak

Vites 2 390-830 /dak

Gerekli hız, karıştırılan malzemenin türüne bağlıdır ve pratik testlerle doğrulanması önerilir.

BAKIM, TEMİZLİK VE DEPOLAMA

UYARI! YARALANMA TEHLİKESİ!

Cihaz üzerinde herhangi bir işlem yapmadan önce cihazı kapatın ve fişi prizden çekin. Makinenin doğru bakımı çalışma ömrünü uzatır. Tutma kolundaki düğme her zaman düzgün çalışmalı ve iyi bakımlı olmalıdır. Karıştırma aparatları kullanımdan sonra veya uzun süre kullanılmayacaksa temizlenmelidir. Cihazı temizlemek için bez kullanın. Genellikle su veya kuvars kumu karıştırma aparatlarını iyi temizler. Kesinlikle benzin veya güçlü çözücüler kullanmayınız. Cihaza sıvı girmesine izin vermeyin. Makineye herhangi bir mekanik baskı uygulamayın, örneğin vurma (Pound), aksi takdirde zarar görür. Karıştırma mili her zaman kirden korunmalıdır. Dişli deliği her zaman koruyucu kapakla kapalı tutunuz. Motor muhafazasının havalandırma delikleri çalışma sırasında kapatılmamalıdır. Makinenin içinde yanıcı maddeler bulunmamalıdır. Havalandırma delikleri sık sık temizlenmelidir. Cihaz ve aksesuarları çocukların erişemeyeceği kuru bir yerde saklayınız. Bu makinede yalnızca orijinal parçalar kullanılmalıdır.

Makine 60 saat çalıştıktan sonra karbon fırçalar kontrol edilmeli ve bakım yapılmalıdır. Fırçanın aşındığı tespit edilirse zamanında değiştirilmelidir. Öncelikle karbon fırça kapağını gevşetin, karbon fırçayı çıkarın ve değiştirin (Her zaman iki fırçayı birlikte değiştirin).

Karbon fırça kapaklarını tekrar vidalayın.

SERVİS MERKEZİ

UYARI! Cihazınızı sadece yetkili servis personeli tarafından ve yalnızca orijinal üretici parçaları kullanılarak tamir ettirin. Bu, cihazınızın güvenli kullanımını sağlar.

UYARI! Güç kablosunun değiştirilmesi gerekiyorsa, bu işlem ancak üretici veya yetkili servis temsilcisi tarafından yapılmalıdır. Böylece güvenlik riski önlenir ve cihazınızın güvenli kullanımı sağlanır.


GERİ DÖNÜŞÜM

Ambalaj tamamen çevre dostu malzemelerden oluşmaktadır ve yerel geri dönüşüm merkezlerinde bertaraf edilebilir.

Elektrikli el aletlerini evsel atıklarla birlikte atmayınız!

Avrupa Direktifi 2012/19/EC uyarınca, kullanılmış elektrikli el aletleri ayrı toplanmalı ve çevreye uygun şekilde geri dönüştürülmelidir.

Kullanılmış cihazlarınızı nasıl bertaraf edeceğiniz hakkında daha fazla bilgi için yerel atık yönetimi kurumunuzla iletişime geçiniz.



CE UYGUNLUK BEYANI

Biz: REİS MAKİNA TİCARET VE SANAYİ A.Ş.
ABDURRAHMANGAZİ MAH. İMAMOĞLU SOKAK NO : 2 SANCAKTEPE/İSTANBUL

Aşağıda detayları verilen ürün beyan edilir:

1600W ELEKTRİKLİ MİKSER

Model: CM1600

Parti No.

Konsey direktiflerinin gereklerini karşılamaktadır:

Makine Direktifi 2006/42/EC

EMC Direktifi 2014/30/EU

ROHS Direktifi 2011/65/EU

Standartlara uygun olduğu onaylar:

EN 62841-1 :2015/A11 :2022

EN 62841-2-10 :2017

EN 62841-1 :2015/A11 :2022

EN 62841-2-10 :2017

AfPS GS 2019 :01 PAK

EN IEC 55014-1 :2021

EN IEC 55014-2 :2021

EN IEC 61000-3-2 :2019 :A1 :2021

EN 61000-3-3 :2013/A2 :2021

IEC62321-2 :2021/ IEC62321-1 :2013/IEC62321-3-1 :2013/IEC62321-4 :2013+A1 :2017/IEC62321-5 :2013/IEC62321-7-1 :2015/IEC62321-7-2 :2017/IEC62321-12 :2023/IEC62321-6 :2015/IEC62321-8 :2017

YETKİLİ SERVİSLER

ADANA

ÖZİŞİKLAR ELEK-ACK MEKANİK
KARASOKU MH.28010 SK.N:4/1
SEYHAN 0322 359 13 33

OMSER TEKNİK / MURAT YILMAZ
YESİLOBA MAH.46023 SOK.NO:11/A
SEYHAN-ADANA
0322 428 92 22-23-24

DEMİR ELEKTRİK
BEKTAŞ DEMİR
KARASOKU MAH. KIZILAY CAD.
28010 SK. NO:4-D-1 SEYHAN
0322 352 97 95

ADİYAMAN
EMEK TEKNİKMAKİNA
REİS SERVİS
ABDULMUSA AKASLAN BOBİNAJ
CUMHURİYET MAH. MUFTULUK CAD.
NO:43 ÇEVREYOLU ÜZERİ MERKEZ
0545 402 02 21

AFYON
EMEK-İŞ BOBİNAJ
ERMAN MANAP
CUMHURİYET MAH. MENDERES CD.
KARAHİSAR APT. 0272 212 11 32

KATAR BOBİNAJ / MUSTAFA
KATAR
SANAİY SİTESİ 6. BLOK NO:27
0272 214 48 64

AĞRI
MAK-TEK SERVICE EL ALETLERİ
YUSUF TOKA
KACIZMAN CAD. BÜLBÜL SK. NO:52
MERKEZ 0554 006 98 97 - 0537 649
41 70

AKSARAY
MERT ELEKTRİK BOBİNAJ
ZEKİ GÜZÜYURDU
BAHÇESARAY MAH. 8637 NOLU
SOK. K6
0382 215 68 33

AMASYA
AKOTEK BOBİNAJ
GÜMÜŞLÜ MAH. SARAYDÜZÜ CAD.
NO:13 0358 218 71 19

ANKARA
GELİŞİM EL ALETLERİ
MUSTAFA ÖVEZ
31.SK. BAŞI TİCARET HAN NO:5
YENİMAHALLE 0312 385 90 98

AYDINER BOBİNAJ ELEKTRİK
SAN.VE TİC. / HÜSEYİN AYDEMİR
REİS SERVİS
1178. CAD. (2.SOK.) NO:89
OSTİM 0312 354 29 28

ANTALYA
GÖKLER MAKİNA / REİS SERVİS
GÖKHAN GÖKLER
CUMHURİYET MAH.ESKİ SAN.SİT.682
SOK.NO:37 MERKEZ 0242 343 21 29

ABALIOĞLU BOBİNAJ
MEHMET ABALI
CUMHURİYET MAH. ASAĞI SAN.
YOLU ÜZERİ ÇAMÇIÇI SİTİNO:9/A
ALANYA 0242 512 63 18

AKTİF BOBİNAJ / REİS SERVİS
HÜSEYİN SARI
SANAİY MAH. 2005 SOK. NO:25/201
MANAVGAT 0242 742 56 29

TEKNİK BOBİNAJ / AHMET KAFALI
YUKARIHİSAR MAH. HASTANE CAD.
NO:12 / A MANAVGAT
0242 746 48 57

AYDIN
KILCIÖĞLU BOBİNAJ
KEREM KILCIÖĞLU
ATA MAH. ALT. SAN. SİT. 1 CAD.
N:6 MERKEZ 0256 214 30 32

ÖZDE OTOMOTİV MAKİNA
YAŞAR AYDIN
ZEYBEK MAH. 1521 SK. NO:4-6D
EFELEİ
0546 453 78 12

ENERJİ TEKNİK BOBİNAJ
EKREM KARABULUT
YENİ MAHALLE 819 SOKAK
BİDAN APARTMANI NO:2-B
DİDİM 0256 811 43 70

AKDENİZ TEKNİK BOBİNAJ
AŞKIN AKDENİZ
CUMHURİYET MH.ALBAYRAK CD.
N:134/ SÖKE 0256 512 63 44

BALIKESİR
TEZGER BOBİNAJ / REİS SERVİS
EREN TESGER
YENİ SANAİY SİTESİ CUMHURİYET
CAD. NO:198/6 MERKEZ
266 246 23 01

SUNAY BOBİNAJ / AHMET SUNAY
YENİ SAN.SİT.19-AĞUSTOS CAD.
NO:28
0266 246 52 70

İLGİN BOBİNAJ / REİS SERVİS
HÜSEYİN İLGİN
17 EYLÜL MAH-HACI ALI SOK.
NO:31/C BANDIRMA
0266 714 51 99

BATMAN
AKTİF BOBİNAJ / REİS SERVİS
HİKMETYAR BİLGE
YENİ MAHALLE 16.CAD. 1008 SOK.
NO:8 0488 214 56 64

BİNGÖL
ÜMİT BOBİNAJ
ABDULLMELİK SUNA
ŞEHİT MUSTAFA GÜNDOĞDU
MH.BAYINDIRLIK CD.SS ESNAF
TÜCC. KOOP.GALERİCİLER SİT.
NO:38 MERKEZ 0544 842 58 00

BOLU
GARANTİ BOBİNAJ
YUNUS ZAFER AKTAŞ
SANAİY SİTESİ 28/2 MERKEZ
0374 215 51 23

BURDUR
ÇEVİKLER BOB. / ÜMİT ÇEVİK
AYDINLIKEVLER MH.KSS.2.SK.15
MERKEZ
0248 252 94 37

BURSA
CANTÜRKLER BOBİNAJ
REİS SERVİS
ADEM CANTÜRK
K-SANAİY SİTESİ YEDEK PARÇ.SİTİÇİ
48.CAD.NO:77 NİLÜFER
0224 253 15 50

TOKER MERT TEKNİK
İBRAHİM TOKER
SAKARYA MAH.1.GÜVEN SOK.
NO:12/A ÇOMUĞAZI
0224 273 54 18

ÇAĞ TEKNİK BOBİNAJ
REİS SERVİS
CENGİZ ESGİN
MAH.MULYIDE MAH.ERTUĞRULGAZI-
CAD.ARMAĞAN SOK.NO:21 İNEĞÖL
0224 715 57 37

ÇANAKKALE
KISAÇIK BOBİNAJ / SAMİ KISAÇIK
NAMIK KEMAL MAH.KAYNAK SOK.
NO:1-C MERKEZ 0286 217 96 71

ŞAHİN BOBİNAJ / HASAN ŞAHİN
İSTİKLAL CAD. NO:154 BIGA
0286 316 11 71

ÇANKIRI
GENÇLER ELEKTRİK&BOBİNAJ
AHMET ALABAY
BUGDAY PAZARI MAH.TALAT ONAY
BULVARI A- BLOK NO:11/2 MERKEZ
0376 213 60 33

ÇORUM
ÖZKAN BOBİNAJ
ÖZKAN SOYLEYEN
GÜLABİBEY MAH. KUBBELİ CAD.
NO:77
0364 224 75 97

DENİZLİ

ÖRSLER BOBİNAJ
SANİM ÖRSÖĞLU
AHI SINAN CAD. SEDEF CARŞISI
NO:9-10 0258 261 42 74

DİYARBAKIR
İKRA BOBİNAJ / REİS SERVİS
SALİH SÜREN
1.SAN.SİT.B/5 BLOK NO:6
0412 237 60 21

DÜZCE
MOTOR MEKANİK BOBİNAJ
ZAFER ÜNAL
ESKİ SANAİY ÇARŞISI TAHIR ALTIN
SOK NO:27 0380 523 87 03

BERKE MAKİNA
AYDIN ÇETİNKAYA
KÜLTÜR MAH.793 SOKAK NO:10
MERKEZ 0380 524 83 83

ERİRNE
ERAY BOBİNAJ / M. ERAY TUĞRUL
KUÇUK SANAİY SİTESİ 4.BLOK
NO:14
MERKEZ 0284 225 26 92

ELAZIĞ
TEKSER TEKNİK
MUAMMER ATALAY
SANAİY SİT. 10. SOK. NO:4
0424 224 83 14

ERZİNCAN
BAKIRÇIOĞLU ELEK. MAK. HIRD.
İNŞ. NAK. SAN. VE TİC. LTD. ŞTİ.
HARUN SUDAŞ / REİS SERVİS
GÜLABİBEY MAH.ŞEHİT KENAN
ARDIÇ CAD.NO:44/A MERKEZ
0446 223 09 59

ERZURUM
TEKNİK MAKİNA BOBİNAJ
MÜKREMIN SEVİNDİ
REİS SERVİS
SANAİY DEMİRCİLER SİTESİ 1.BLOK
NO:46 YAKUTİYE
0442 243 17 34

ESKİŞEHİR
TEPEBAŞI TEKNİK SANAİY VE
TİC.LTD. ŞTİ.
TUNALI MAH. SEMT. SAKARYA-2
CAD. NO:96 D TEL:0222 323 59 80

GAZİANTEP
YILDIZ BOBİNAJ / REİS SERVİS
MEHMET KOÇYİĞİT
İSMETPAŞA MAH.1. NOLU CAD.
NO:23/F ŞAHİNBEY
0342 221 15 74

ÇALIKOĞLU BOBİNAJ
TOLGA ÇALIKOĞLU
KÜŞGET SAN.MAH.SEMT 60031
NOLU CD.1 ŞEHİTKAMİL
0342 235 63 09

PARLADI ELK. BOBİNAJ
2.ORGANİZE SAN. BÖLG.SOSYAL
TESİSLER B BLOK NO:4 BAŞPINAR
0342 337 74 87

GİRESUN
ÖZCAN TEKNİK BOBİNAJ
DENİZ ÖZCAN
GEDİKKIYMA MAHALLESİ SANAİY
SİTESİ 6.SOKAK NO:5 MERKEZ
0454 212 17 35

HATAY

PAK İŞ ELEKTRİK
REİS SERVİS
MUZAFFER PAK
HARAPARASI MAH.
2.CAD.NO:7 ANTAKYA
0326 215 64 73 - 0326 221 15 45

PAK İŞ ELEKTRİK&ŞUBE
YENİ SANAİY SİTESİ 6.İNİŞ 4. CAD.
GÜZELBURÇ NO.10 ANTAKYA
0323 215 64 73

KAR BOBİNAJ / REİS SERVİS
ABDULLAH KAR
GÜZELBURÇ MAH. 6. İNİŞ CAD. NO:12C
ANTAKYA 0246 223 70 11

ULUSAL TEKNİK
ESREF EZBER
MURADİYE MH. 324/1 SOK. NO:29
İSKENDERUN 0326 616 09 31

İSPARTA
İZMİR BOBİNAJ / REİS SERVİS
EMİN ÖZSÖY
YENİ SANAİY SİTESİ
6.BLOK NO:28 0246 223 70 11

İSTANBUL-ANADOLU
AYKUT ELEKTRİK
REİS SERVİS
ERTAN KESKİNOĞLU
KARLIKTEPE MAH.SOĞANLIK CAD.
KESKİNOĞLU APPT.NO:78/B KARTAL
216 488 04 56/42-68

ERMAK GRUP TEK. SERVİS
REİS SERVİS
İSKENDER KÖSE
ALTINŞEHİR MAH. ALEMDAĞ CAD.
NO:626 ÜMRANİYE
216 540 46 28

PRATİK ELEKTROMEKANİK
REİS SERVİS
S. ALİ TUĞANLI
ALEMDAG CAD. RUZGARLI SOK.
NO:9/2 ÜMRANİYE
0216 344 03 50

SÖNMEZ ELEKTROMEKANİK
REİS SERVİS
NIHAT ÇELİK
AYDINTEPE MAH. YAVUZ CAD.KÖŞE
SOK.NO:5/3 TUZLA
0216 493 72 41

İSTANBUL-AVRUPA
DEMİRHAŞ MAKİNA / REİS SERVİS
SAİM DEMİRHAŞ
PERPA TİC.MERKEZİ B BLOK KAT:8
NO:995 ŞİŞLİ 0212 320 22 61

ERMAK MAKİNA / REİS SERVİS
DAVUT KÖSE
PERŞEMBE PAZARI CAD.ÖMER AĞA
SOK.NO:11 KARAKÖY
0212 252 33 95

EVREN ELEKTRİK
MUSTAFA MERŞİN
TERSAANE CAD HOCA HANIM SOK
NO:23/1 KARAKÖY
0212 254 56 77

YILMAZLAR ELEKTRİK
YILMAZ ÖMERÖĞLU
TERSAANE CAD.ABDÜLSERRAH SOK
NO:8 KARAKÖY 0212 297 15 02

KARDEŞLER BOBİNAJ
REİS SERVİS
MURAT DEMİRHAŞ
GURSEL MAH. KAĞITHANE CAD.
NO:34/A
0212 224 97 54

YETKİLİ SERVİSLER

TEZCAN BOBİNAJ / REİS SERVİS
MEHMET TEZCAN
İKTELLİ ORGANİZE SANAYİ BÖLGESİ
ESKOOP SAN. SİTESİ B2 BLOK
NO:116 BAŞAKŞEHİR
0212 671 20 93/94

NUR TEKNİK BOBİNAJ
ABDULLAH ERKAN
PIRİ MEHMETPAŞA MAH.
BURHAN SOYSALAN SOK.NO:21
SİLİVRİ
0212 727 32 03

İZMİR
İRFAN BOBİNAJ / REİS SERVİS
İRFAN MAKİNACI
1310 SOK. NO.41/B ÇANKAYA
0232 425 35 49

ÇATALSU ELEKTRİK
NURAY ŞAHBUDAK
HİRDAVAÇILAR CARŞISI
1145/11 SOK.NO:9 YENİŞEHİR
0232 459 58 29

YILMAZ BOBİNAJ
2822 SOK.NO:2 1. SAN. SİT.
KONAK 0232 433 80 51

KENT BOBİNAJ
ÖMER KÖMÜRCÜ
8780/33 SOK.NO:50 ATA SAN. SİT.
ÇİĞLI 0232 328 10 33

MY TEKNİK SERVİS HİZM.
İNAL ÖZER
YEDİ EYLÜL MAH.5542 SOK.NO:39
İÇ KAPİ NO:1 TORBALI
0232 856 35 34

K.MARAS
KAHRAMAN HIRDAVAT BOBİNAJ
MESUT KURU
YENİ SANAYİ SİTESİ 25. CARŞI NO:68
DULKADIRIOĞLU 0344 236 29 68

ONURSEL ELEKTRİK ELEKTRONİK
BOB.TA.IT.İH.SN.TIC.LTD.ŞTİ
YENİ SANAYİ SİTESİ 5.CARŞI NO:99
MERKEZ 0344 236 10 24

ÜSTÜN BOBİNAJ
TUĞRUL ÜSTÜN
YENİ SANAYİ SİTESİ 9.BLOK NO:14
ELBİSTAN 0344 413 64 93

KARABÜK
DAMLAM ELEKTRİK
ABDULLAH ERDOĞAN
HURİYET MAH.İNÖNÜ CAD. AKTAŞ
SOK.17/B 370 412 77 00

KARAMAN
UZUN ELEKTRİK BOBİNAJ
RAMAZAN UZUN
HAMİDİYE MAH. YENİ SANAYİ SİT.
1866 SK. NO:15 MERKEZ
0338 213 70 79

MECHANİC ELEK. BOBİNAJ
DURMUŞ PANCAR
HAMİDİYE MAH. 735 SOK. NO:2
0338 213 10 20

KASTAMONU
NUR BOBİNAJ / MUSTAFA SAKAR
SAN.SİT.CAMI CAD.NO:29/A MERKEZ
0366 214 61 18

TABAKOĞLU BOBİNAJ
ALAEETTİN TİFTİK
METAL SANAYİ SİT.AZZİYE SOK.
N:1/3 TOSYA 0366 313 04 31

KAYSERİ
AKIN ELEKTRİK / REİS SERVİS
AHMET VAROL
SANAYİ BÖLGESİ
5. CAD. NO:8 0352 311 41 74

AKIN ELEKTRİK / REİS SERVİS
MEHTAP AYBEY
SANAYİ MAH.6005 CAD.8 D
KOCAŞINAN
0352 336 41 23

KIRKLARELİ
YALÇIN SOĞUTMA HAV.BOB.
MESUT YALÇIN
GÜNDOĞU MAH.FATİH CAD NO 95
LÜLEBURGAZ 0288 412 01 49

VATAN ELEKTRİK / ERTAN VATAN
KOCAŞINAN MAH.ÇAKMAK SOK.
ÇERİ APRT.NO:22/C LÜLEBURGAZ
0288 412 91 90

KOCAELİ
ÇETİNKAYA ELEKTROMEKANİK
REİS SERVİS
NECMETTİN ÇETİNKAYA
SANAYİ MAH. İZMİT SAN.SİT.12
CAD. 11.BLOK NO:1 İZMİT
0262 335 13 20

İNCE MOTOR BOBİNAJ
REİS SERVİS
ERSİN İNCE
MUSTAFA KEMALPAŞA MAH. 712 SOK.
NO:26 GEBZE
0262 646 46 15

KONYA
TEKYAMAN BOBİNAJ
REİS SERVİS
ETHEM YAMAN
FEVZİ ÇAKMAK MAHALLESİ 10563
SOK.NO:7 KARATAY
0332 342 68 50

YAVUZHAN BOBİNAJ
ADEM YAVUZ
KARATAY SANAYİ ÇOBANDEDE SOK.
NO:20 SELÇUKLU
0332 233 29 60

UĞUR SONDAG BOB. SAN. TİC.
ZYA GÖKALP MAH. TÜRKMEN KÖYÜ
CAD. NO:36 EREĞLİ
0332 710 07 77

KÜTAYHA
KÜDRET BOBİNAJ
YENİ SAN. SİT. 19. SOK. NO: 28
MERKEZ 0274 230 00 14

MALATYA
KAPLAN BOBİNAJ
MEHMET KAPLAN
ÇAUSOĞLU MAH.YENİ SANAYİ SİTESİ
İMALAT SOK. NO:4 YEŞİLİYURT
0422 336 92 67

MANİSA
İRFAN BOBİNAJ
HAKAN MAKİNACI
GÜZELYURT MAH. M. AKİF ERSOY
CAD. 20. SK. BLOK NO:86/A
0236 236 22 96

KARDEŞLER ELEKTRİK BOBİNAJ
SANAYİ SİTESİ 4 NOLU SOK.
NO:2 ALAŞEHİR 0236 6543435

MARDİN
TENSEN BOBİNAJ / REİS SERVİS
ERSEN-ERTEN ÇELİK
YENİŞEHİR M.H.RAVZA CD.49.SK.
N:7/15 ARTUKLU
0482 213 37 62

MERSİN
COŞKUN BOBİNAJ / REİS SERVİS
SEDAT COŞKUN
SİTELER M.H.SANAYİ SİTESİ 5678 SK.
G31 BLOK N:4/K AKDENİZ
0536 940 06 93

MUĞLA
HIZIR BOBİNAJ
MURAT HIZIR
SANAYİ SİTESİ DEMİRÖZ SOKAK
NO:20 BODURUM
0252 313 61 69

MERKEZ BOBİNAJ İNŞ. LTD. ŞTİ.
TUZLA MAH. İNÖNÜ (TSY) BLV.
NO:7/B İÇ KAPİ NO:1 FETHİYE
0252 612 10 51

EYÜP BOBİNAJ
EYÜP TİRİMOĞULLARI
ULUSAL EGEMENLİK CD.N:87
MARMARİS 0252 412 14 50

NEVŞEHİR
ARICAN BOBİNAJ / REİS SERVİS
ERHAN ARICAN
YENİ SANAYİ SİTESİ
36 CI DUKKANLAR NO:28 MERKEZ
0384 213 53 11

NİĞDE
GÜL BOBİNAJ / REİS SERVİS
ÖMER ÜÇGÜL
ŞAHİNALI M.H ŞEHİTBAYRAMAKSOY
SOKAK NO:18 MERKEZ
0534 386 40 09

ORDU
ERKA BOBİNAJ / REİS SERVİS
KAAN BASKIN
MUSTAFA KEMALPAŞA MAH.
PARK SOK.NO:17 İÇ KAPİ:1
0543 600 38 02

KAHVECİOĞLU ELEKTRİK
CUMHUR KAHVECİ
DURUGÖL MAHALLESİ ATATÜRK
BULVARI NO:487/A
0452 233 13 35

SİMGE SOĞUTMA
DUMLUPINAR MAH. PAZAR SK. N:35
ÜNYE 0452 233 13 35

RİZE
KOYUNCULAR TEKNİK
REİS SERVİS
EYÜP KOYUNCU
TOPHANE MAH.KAÇKAR CAD NO:9
MERKEZ 0464 217 37 31

CEMBERÇİ BOBİNAJ
MEHMET CEMBERÇİ
ENGİNERE MAH. SAN. SİT.
F BLOK: NO:20 MERKEZ
0464 217 45 00

MERKEZ BOBİNAJ -
MUHAMMET BİRİNCİ
EKREM ORHON MAH. HANIMELİ SK.
NO:4/B 0464 212 20 05

SAKARYA
ENGİN ELEKTRİK
ENGİN DURMUŞ
MALTEPE MAH. ORHAN GAZİ CAD.
(TEK YOKUŞU) ŞEHİT METİN AKKUŞ
SOK. NO:19 0264 291 05 67

İR MAKİNA
FATİH İR
FEVZİ PAŞA CAD. ÇARK SAN.
SİT:N:36 SERDİVAN 0264 279 01 81

2V MEKATRONİK / REİS SERVİS
VEDAT AMASYALI
GÜNEY MOB.SAN.SİT:1288
SK.N:11/A ERENLER
0264 666 18 19

SAMSUN
AS BOBİNAJ / KANİ ASAL
SANAYİ SİTESİ AHİEVAN CAD.
NO:38 ÇANIK
0362 238 09 66

UFUK BOBİNAJ TİCARET -
MAHMET SERKAN SİMGA
YENİ MAHESKİ SANAYİ SİTESİ
1.SOK. NO:14 ÇANIK
0362 238 07 40

İŞILDAK BOBİNAJ
MELİH İŞILDAK
ALACAĞAM CD. BELEDİYE DUKKANLARI
NO:115 BAĞRA 0362 543 10 49

METİN BOBİNAJ - ADEM METİN
REİS SERVİS
ESKİ SAN. SİT. KILIÇARSLAN CAD.
NO:49 0362 228 64 25

SİVAS
DOĞAN TEKNİK ELEKTRİK
MAKİNA
KEREM DOĞAN
PAŞABEY MAH.HAYRAT SOK.
SURTAS APRT. ALTI NO:2/C
MERKEZ 0507 707 57 58

ŞANLIURFA
AKSAN BOBİNAJ
HALİL ÇİMENOĞLU
REİS SERVİS
SANAYİ SİT.ÇEŞUR CD.N:47 CAD.
NO:48 HALILIYE
0414 314 17 38

TEKİRDAĞ
ÇETİN ELEKTRİK BOBİNAJ
REİS SERVİS
EROL ÇETİN
100.YIL MAH. MEHMET İLHAN SOK.
NO:12/1 C SÜLEYMANPAŞA
0282 263 86 60
TRAKYA BOBİNAJ ELEKTRİK
NECATİ AKMAN
SEYHİNAN M.H.EREĞLİ SK.
KLAVUZ İŞ HANI NO:2 ÇORLU
0282 653 27 77

ÖZYL ELEKTRİK ENDÜSTRİYEL
SERVİS
KURTULUŞ YILDIRIM
GAZİ ÖSMAN PAŞA MAH. ALIAGA SK.
NO: 4 A ÇERKEZKÖY
0282 726 67 04

TOKAT
ÇETİN ELEKTRİK BOBİNAJ
MUSTAFA ÇETİN
SANAYİ SİTESİ CAMİ ALTI NO.13-18
0356 214 63 07

TRABZON
DİNÇ BOBİNAJ - AYHAN DİNÇER
REİS SERVİS
BÜYÜK SAN. SİT SOS. HİZ. BİN.
NO:3-B DEĞİRMENDERE
0462 325 22 02

MAKİNA MARKET
AHMET SALİH ŞAHİNER
SANAYİ MAHALLESİ DOST SOK.
NO:69 ORTAHİSAR
0462 328 14 80

VAN
ÇAĞRI BOBİNAJ
MUHAMMED REŞİT COŞAR
CUMHURİYET CAD.ALÇEKİÇ PAŞALI
NO:10 MERKEZ
0531 514 64 51


YALOVA
UFUK ELEKTRİK BOBİNAJ /
HÜSEYİN BALCIOĞLU
SÜLEYMAN BEY MAH.İSTİKLAL
CAD.24/D MERKEZ
0226 811 32 45

ZONGULDAK
AYTEKİN ELEKTRİK
MUSTAFA AYTEKİN
KIŞLA SAN. SİTİ BLOK NO.24
K.EREĞLİ
0372 316 39 71



reismakina
“Kalitenin Yapı Merkezi”

Reis Makina Ticaret ve Sanayi A.Ş.
Abdurrahmangazi Mh. Ebubekir Cd. İmamoğlu Sk.
No: 2 34887 Samandıra / Sancaktepe / İSTANBUL / TÜRKİYE
Tel: +90 444 73 47 (REIS) Faks: +90 (216) 561 4688
www.reismakina.com





FACTOR

ELECTRIC MIXER

USER MANUAL

CM1600



The following symbols may appear in these operating instructions or on the device.



WARNING – To minimize the risk of injury, the user must read the operating instructions.



Do not work with materials containing asbestos.



Wear a dust mask.



Do not work without protective eyewear.



Wear hearing protection.



Class II device



Dispose of the packaging and device in an environmentally friendly manner.

INTRODUCTION


Please make sure you familiarize yourself fully with the way the device works before you use it for the first time and that you understand how to handle electrical power tools correctly. To help you do this please read the accompanying operating instructions. Keep these instructions in a safe place. If you pass the device on to anyone else, please ensure that you also pass on all the documentation.

PROPER USE

The machine is only intended for mixing concrete, cement or paint. Improper use may damage the tool. Any other use or modification to the device shall be considered as improper use and could give rise to considerable risk of accident. The manufacturer will not accept liability for loss or damage arising from improper use. The device is not intended for commercial use.

FEATURES

1. ON / OFF switch
2. Switch lock
3. Speed control wheel
4. Speed selector switch
5. Tool mount
6. Supplementary handle
7. Ventilation apertures
8. Wrench
9. Whisk



Included items

- 2 wrenches
- 1 Operating instruction

TECHNICAL DATA

Nom. Voltage	: 230V ~ 50 Hz
Rated Power	: 1600W
No-load speed	: I: 240-500/min, II: 380-850min
Spindle size	: M14
Whisk	: $\varnothing$ 140 mm
Weight	: 5.0 kg
Protection class	: II / 

NOISE AND VIBRATION DATA

Values determined in accordance with EN 60745.

The sound pressure level (LpA) of the device is typically 88, 3 dB (A). Uncertainty K = 3 dB.

The sound power level (LwA) of the device is typically 99, 3 dB (A). Uncertainty K = 3 dB.

Wear ear protection!



Main handle

Max. Vibration emission value is 1,812 m/s²; Uncertainty K = 1,5 m/s²

Auxiliary handle

Max. Vibration emission value is 2,439 m/s²; Uncertainty K = 1,5 m/s²

Note:

- that the declared vibration total value has been measured in accordance with a standard test method and may be used for comparing one tool with another; that the declared vibration total value may also be used in a preliminary assessment of exposure.

Warning:

- that the vibration emission during actual use of the power tool can differ from the declared total value depending on the ways in which the tool is used; avoid vibration risk suggestion:

1) wear glove during operation

2) limit operating time and shorten trigger time

GENERAL POWER TOOL SAFETY WARNINGS

WARNING Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

1. Work area safety

- a) Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- b) Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- c) Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

2. Electrical safety

- a) Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- b) Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- c) Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- d) Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- e) When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.
- f) If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.

3. Personal safety

- a) Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- b) Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- c) Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.
Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- d) Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- e) Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- f) Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- g) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards.

4. Power tool use and care

- a) Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- b) Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- c) Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- e) Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- g) Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.

5. Service

- a) Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

Caution utility services!

DANGER! Ensure that you do not strike electrical cables, gas or water pipes when you are working with the electrical power tool. Check a wall using a suitable detector before you drill or cut slots.

Original accessories / attachments.

Use only the accessories and attachments detailed in the operating instructions.

The use of inserted tools or accessories other than those recommended in the operating instructions could lead to you suffering an injury.

BEFORE FIRST USE

WARNING! DANGER OF INJURY! Switch the device off and pull the plug out of the mains socket before carrying out any work in the device.

Placing a whisk

NOTE: Use only whisks conform the specified diameter.

Screw the whisk with thread (M14) as far as possible in the tool
Tighten the whisk properly with an open-end wrench.

First use

The mains voltage at the mains socket must match that shown on the rating plate on the device.

Using

Improper use may damage the instrument. Observe therefore these instructions:

Use a tool up to the specified diameter.

Load the tool in such a way that the speed would not drop considerably or that it would stop.

Check if the data on the rating plate correspond with the actual mains voltage.

Switching on and off

To switch on the tool, press and hold the on/off switch (1).

If you release the on/off switch, the tool will be switched off.

Switch locking mechanism

You can lock the on/off switch by pressing the on/off switch (1) and then button (2). The switch lock can be released by briefly pressing the on/off switch.

Infinitely adjustable speed setting

Two rpm ranges can be pre-selected with the speed selector switch (4):

Gear 1 220-500 /min

Gear 2 390-830 /min

The necessary speed depends on the type of the material mixed and it is recommended to verify it by a practical test.

MAINTENANCE CLEANING AND STORAGE

WARNING! DANGER OF INJURY!

Switch the device off and pull the plug out of the mains socket before carrying out any work on the device.

Correct maintenance for the machine can prolong the working life; The handle switch must always keep in proper function and good maintenance;

The mixing tools should be cleaned when the operation is finish or no use for long time; Use a cloth to clean the device.

Normally the flowing water or quartz sand can clean the mixing tools well. Do not under any circumstances use petrol or strong solvents. Do not allow any liquids to enter the device.

DO not fore any mechanical stress in the machine, such as POUND, because it will be unavoidable damaged;

The mixing shaft must always be antipollution; The threaded hole must always be put protecting cover;

The vent of motor housing can not be covered when the machine is in operation, there can not be any flammable materials in the machine;The vent must be often cleaned;

Store the device & accessories in a dry room where out of the reach of children also.

Only original parts can used in this machine.

The carbon brush must be checked and maintenance when the machine operation up to 60hours, please change the brush in time if find the brush worn out.

Loosen carbon brush cap first, Pull out and replace the carbon brush (Always replace the two brushes at the same time), screw carbon brush caps.

SERVICE CENTRE

WARNING! Have your device repaired only by qualified specialist personnel using original manufacturer parts only. This will ensure that your device remains safe to use.

WARNING! If the replacement of the supply cord is necessary, this has to be done by the manufacturer or his agent in order to avoid a safety hazard. This will ensure that your device remains safe to use.

DISPOSAL


The packaging is wholly composed of environmentally-friendly materials that can be disposed of at a local recycling centre.

Do not dispose of electrical power tools with the household rubbish!

In accordance with European Directive 2012/19/EC, worn out electrical power tools must be collected separately and taken for environmentally compatible recycling.

Contact your local refuse disposal authority for more details of how to dispose of your worn-out devices.

ELECTRIC MIXER CM1600



CE DECLARATION OF CONFORMITY

Declare that the Product detailed below:

1600W ELECTRIC MIXER

Model: CM1600

Batch no.

Satisfies the requirement of the Council Directives:

Machinery Directive 2006/42/EC

EMC Directive 2014/30/EU

ROHS Directive 2011/65/EU

and confirms with the norms:

EN 62841-1 :2015/A11 :2022

EN 62841-2-10 :2017

EN 62841-1 :2015/A11 :2022

EN 62841-2-10 :2017

AfPS GS 2019 :01 PAK

EN IEC 55014-1 :2021

EN IEC 55014-2 :2021

EN IEC 61000-3-2 :2019 :A1 :2021

EN 61000-3-3 :2013/A2 :2021

IEC62321-2 :2021/ IEC62321-1 :2013/IEC62321-3-1 :2013/IEC62321-4 :2013+A1 :2017/IEC62321-5 :2013/IEC62321-7-1 :2015/IEC62321-7-2 :2017/IEC62321-12 :2023/IEC62321-6 :2015/IEC62321-8 :2017

Position of Signatory:

Director of International Buying



reismakina
“Kalitenin Yapı Merkezi”

Reis Makina Ticaret ve Sanayi A.Ş.
Abdurrahmangazi Mh. Ebubekir Cd. İmamoğlu Sk.
No: 2 34887 Samandıra / Sancaktepe / İSTANBUL / TÜRKİYE
Tel: +90 444 73 47 (REIS) Faks: +90 (216) 561 4688
www.reismakina.com

